





FIG. 2

0
Ō
4
_
`

The state of the s

REJECT		n self	lesh	poke		REJECT						1		ACCEPT		Hise
Default: REJECT	Comment	No routes from self	ACCEPT Import from Mesh	ACCEPT Import from Spoke		Default: REJECT	Comment		Export to Mesh		Export to Hub			Default: ACCEPT	Comment	REJECT Do not readvertise
	Action	REJECT	ACCEPT	ACCEPT			Action	ACCEPT		ACCEPT					Action	REJECT
	Next Hop	any	any	any			Next Hop Action	any	p/u	any	D/u				Next Hop	any
	IPv4	any	any	any			Pv4	any	11	any	п			H	lPv4	any
	VPN	any	any	any			VPN	any	Client Intranet	any	Client Intranet				VPN	any
	Site	Site 3	any	any			Site	any	Site 3	any	Site 3				Site	any
	RT	any	Tm(101.1)	Ts(100.2)			RT	any	Tm(101.1)	any	Th(100.1)				RT	any
	ß	any	any	any	Se		2	any	D(101.3)	any	D(100.3)		nles		æ	any
5017	Type	Auto	Anto	Auto	ort Ruk		Type	Auto		Auto			xport Ru	.	Type	Auto
cein vine	Rule #		2	3	-Local Export Rules		Rule #			2			Remote Export Rules		Rule #	

<u>.</u>

ㅎ

4/4









